

These brief instructions show the procedure for installing the **iGyro 1e** in just a few minutes, without any PC programming. If you need to access additional functions, they can be set up using the USB lead and a PC or laptop. The **Terminal Program** required for this is available free of charge, and includes a **Quick Tip** function which explains all the gyro's features in detail. The procedure the gyro's features in detail. The procedure for setting up the iGyro 1e using the USB interface and the Terminal program can be found in our PowerBox Support Forum at forum.powerbox-systems.com

The effect of the iGyro 1e is shown here in graphic form



**Note:** Do not fix the **iGyro** in place until you have checked its direction of effect.

2. Connect the **INPUT** lead to the receiver's

- control channe then connect one or two servos to OUTPUT 1 and 2.
- At the transmitter assign a gain channel to a rotary knob or linear slider, with a working range of -100% to +100%. Connect this channel output to the **GAIN** input on the gyro.

- 4. Switch on your transmitter and receiver, and check the appropriate control funct-ion: if you need to reverse an output, or adjust the servo centre or endpoints, you can carry this out conveniently using a PC, the USB Interface Adapter and the free Terminal Program.
- Turn the gain control to the 100% end-point, and check the gyro's direction of effect on all axes. check the gyro's direction of
- 6. If the direction of effect is reversed, you
- If the direction of effect is reversed, yo can correct it in either of two ways:
  Turn the IGyro 1e round, and secure it.
  However, this only works if you are only using one output, or if the direction of effect is incorrect for both outputs.
  Connect the IGyro 1e to a PC using the USB Interface Adapter. You can now adjust the direction of effect for both outputs using the PowerBox Terminal program. program
- The iGyro 1e is now ready for use. First disable the gyro by moving the slider or knob to centre.
- 8. Launch the model, and fly parallel to the runway. Increase gyro gain until the aeroplane just starts to oscillate, then turn the gain control back until the model shows no tendency to oscillate at any speed. If you are flying the model in flat calm conditions, it can be helpful to give the gyro a little "work" to do: flick the sticks a little, and check that the model accurately mainand check that the model accurately maintains its heading, and does not oscillate after the movement.

The iGyro 1e has two ranges which can be adjusted:

Range A, gain control 0% to +100%: by default this is set to Rate mode only. Range B, gain control 0% to -100%: by default a value is set here for Attitude Assist mode in addition to the Rate value. -100%

Range B Range A

Attitude Assist Mode: The iGyro 1e assists the model maintain the attitude of the model in the attitude it was positioned in roll or pitch or yaw (depending on which axis you are using the iGyro) at the last given control input. As any control input in pitch or roll or yaw is applied by the pilot the Attitude assist will gradually phase out. This highly developed stick authority software is what provides the 1e with unprecedented levels of control and moves away from gyro interaction that some other lesser gyros suffer from.

**Note:** Both ranges can be configured in any way you like using the **Terminal Software**.

**Note:** Once you have test-flown the model to establish the correct gyro gain values, you can substitute a three-position switch for the rotary control, and use the switch to set the **iGyro 1e** to your preferred settings.

#### Example:

Switch position 1: gain ± 0%, Switch position 2: gain +45%, gyro in Rate mode 0%, gyro off

+100%

Switch position 3: gain -40% gyro in Attitude Assist mode

Naturally your own values may differ mar-kedly from those stated, as they need to be established individually for each model.

Another feature of the **iGyro 1e** is that it always stores the current gain value. This means: if you do not have a spare channel, you can use a channel once to set up the gyro to a particular gain value, and then switch it off, disconnect the gain input from the receiver. The next time you switch on, the **iGyro 1e** will operate with the last gain value you set, so you can re-use the receiver channel for another purpose.

The second option is to set a fixed gyro gain value using the PC and the **Terminal Program**.



# **CAUTION**

Two important rules for using the iGyro 1e in everyday flying:

- ot process is complete before switching the receiver on.

  2. Always carry out a check of the control surface movements, taking care to move the
- sticks to both end-points

### **SERVICE NOTE**

We make every effort to provide a good service to our customers, and have esta blished a Support Forum which covers all queries relating to our products. Please use the Support Forum

www.forum.powerbox-system **before** you telephone us.



# **GUARANTEE CONDITIONS**

That is why we are able to grant a **24 month** guarantee on our iGyro **1e** from the initial date of purchase. The guarantee covers proven material faults, which will be corrected by us at no charge to you.

The guarantee does not cover damage caused by incorrect usage, e.g. reverse polarity, excessive vibration, excessive violage, damp, fuel, and short-circuits. The same applies to defects due to severe wear.

# LIABILITY FYCLUSION

We are not in a position to ensure observe our instructions regarding installation of the **iGyro 1e**, fullfil the recommended conditions when using the unit, or maintain the entire radio control system competently.

For this reason we deny liability for loss, which arise due to the use damage or costs or operation of the **iGyro 1e**, or which are connected with such use in any way. Regardless of the legal arguments employed, our obligation to pay damages is limited to the invoice total of our products which were involved in the event, insofar as this is deemed legally permissible.

We wish you every success using your new **iGyro 1e**!



Donauwörth, April 2024